

Manufacturer's Recommendation for Installation of Single and Double Threshold Shower Bases and Shower Stalls

1. Place shower base into desired opening and shim it to be level
2. Mark a line on the studs where the tile flange ends.
3. Remove the shower base.
4. Measure from the top of the shower base to the bottom of the outside fiberglass ledge.
Transpose that measurement to the wall and draw a new level line on the studs.
5. Install a cleat on the wall for the base to rest on so it will hold it level.
6. Prepare drain fittings.
7. Mix thin set or mortar and pile around center of the shower base
8. Place the shower base back into desired opening.
9. Rock gently back and forth to work support mix out of the way until shower base comes to rest on the leveling cleat installed to studs
10. Drill holes through acrylic and fiberglass flange into the adjoining studs
11. Secure to studs with 1 ½ " screws

It is recommended that all of our products be installed on a bed of thin set concrete or mortar mix. This will stop any shifting or squeaking, and remove potential leak problems caused from flexing of the shower base. See illustration below.

